

## PSA Veneer Installation Guide

### Surface Preparation:

All surfaces require preparation before applying any peel and stick veneer. For surfaces that have already been finished, lightly scuff the existing finish with a medium (120 grit) sandpaper. Remove all sanding dust and particles with tack cloth or wipe entire surface with a clean cloth and denatured alcohol or other suitable cleaning solvent. When applying veneer over plywood, real wood or any other porous substrate it is best to seal the surface first with shellac, varnish, polyurethane or any sealer. Allow 24 hours for sealer to dry then continue with veneer application.

### Applying Veneer:

Cut veneer to a slightly larger dimension than actual size of area you are covering. This will allow you to place the veneer without having to be perfectly aligned with the surface being veneered. Place the veneer and begin applying pressure from the center out to avoid trapping air pockets in the center. To apply adequate pressure to the veneer, it is best to use a stiff bladed scraping tool or wooden scraping block. Bear down with as much pressure as possible and draw the scraper toward you in the same direction as the grain. Repeat this pattern until you are sure you've gone over every square inch.

### Trimming The Veneer:

When trimming the veneer to the finished size, use a sharp razor knife or utility knife and cut the veneer back to the edge of the workpiece. It is best to score your cut a few times before actually cutting through to prevent wood tearout. This is especially important when cutting across the grain. After trimming the veneer you will probably notice a sharp corner or edge. To ease this edge you can use a fine cabinet file held at a 45 degree angle and lightly run along the edge or if this option isn't available to you, use a fine grit sandpaper and lightly feather the edge with the sandpaper.

### Finishing Veneer:

Veneer can be finished just like any hardwood. The first step is proper sanding starting with a medium grit paper followed by a fine grit paper. This can be done with an electric sander if you are confident enough or by hand if you are not. From this point you can either stain the wood or finish with a clear finish. For finishing tips consult our website at [www.oakwoodveneer.com](http://www.oakwoodveneer.com) or call with specific questions at (800) 426-6018.

### Oakwood Veneer Company

1830 Stephenson Hwy.

Troy, MI 48083

(248)-720-0288

Toll Free (800) 426-6018

[www.oakwoodveneer.com](http://www.oakwoodveneer.com)